

Installation Instructions for Awning Clothesline.

1. Roll Out the awning.
2. Check that there is clearance on the inside of the awning arm, you need about 3mm.
3. Measure down from the top of the awning your desired distance I recommend 200mm.
- 3a. Measure down a further 200mm or 300mm and mark if you are installing a second cable. Please ensure that you have clearance on the second cable to the top of the door.
4. Mark with a pencil the 200mm and the centre of the inside awning arms both sides.
5. Drill an 8.5mm hole on the pencil marks, on the inside of BOTH awning arms.
6. Take the Hex Female Adjuster off both ends of the stainless steel cable.
7. Insert the MALE threaded part through the hole and do up the hex adjuster.
8. TURN THE ADJUSTER NOT THE CABLE.
9. Do this for both sides of the line.
10. Get a 5mm allen key and tighten the adjuster till the line is taut.
11. Take a 10mm spanner and nip up the lock nut on both side of the line.
12. If for some reason the line will not go taut enough then take off one or both the lock nuts. They are not really needed.



CAUTION.

DO NOT OVER TENSION THE LINE AS IT WILL CAUSE THE AWNING TO DISTORT AND NOT OPERATE SMOOTHLY. IF YOU HAVE TOO MUCH TENSION ON THE LINE AND THE AWNING DOES NOT OPERATE PROPERLY, BACK OFF THE ADJUSTERS A BIT TILL THE AWNING IS OPERATING PROPERLY.